OFF ON ON SLEEP WAKE MODE

It is important to read this user manual prior to using your new product for the first time. andons de lire ce manuel d'instructions avant d'utiliser votre nouveau produit pour la première fois.

prior notice.

For your records

In the event that service should be required, you may need the model number and the serial number. In the space below, record the date and place of purchase and the serial number: Model No.: Date of Purchase

Place of Purchase: Serial No.: Technical information

Product: Clock Radio

Brand: RCA Electrical consumption

Power Supply: 120V ~ 60Hz Power Consumption: 5 Watts

The descriptions and characteristics in this owner's manual are for the purpose of general reference only and not as a guarantee. In order to provide you with the highest quality product, we may make changes or modifications without

FCC information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation This equipment generates, uses, and car radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

following measures:

Reorient or relocate the receiving

CAUTION

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK), NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

SEE MARKING ON BOTTOM OF PRODUCT

OF ELECTRIC SHOCK DO NOT OPEN

- antenna Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to

Canada.

HE EXCLAMATION RIANGLE IS A LERTING YOU O ISTRUCTIONS

THE PRODUCT

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD. DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du

Maufacturer/Responsible Party Audiovox Electronics Corp. 150 Marcus Blvd., Hauppauge, NY 11788 Some of the following information may

- not apply to your particular product; however, as with any electronic product, precautions should be observed during ndling and use.
- Read these instructions Keep these instructions Heed all warnings. Follow all instructions
- Do not use this apparatus near water.
- · Clean only with dry cloth. Do not block any ventilation
- openings. Install in accordance with the manufacturer's instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including

amplifiers) that produce heat.

- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into vour outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles. and the point where they exit from the apparatus.

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

IMPORTANT SAFETY INSTRUCTIONS

Only use attachments/accessories Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, specified by the manufacturer. Use only with the cart, stand, tripod, bracket, or table specified by shall be placed on the apparatus Always leave sufficient space around the manufacturer, or the product for ventilation. Do sold with the apparatus.

not place product in or on a bed, rug, in a bookcase or cabinet that may prevent air flow through vent Do not place lighted candles,

cigarettes, cigars, etc. on the product. Connect power cord only to AC power source as marked on the

product. Care should be taken so that objects do not fall into the product.

Do not attempt to disassemble the cabinet. This product does not contain customer serviceable The marking information is located

at the bottom of apparatus Caution marking is located at bottom of apparatus.

This is CLASS II apparatus with double insulation, and no protective earth provided.

Important Battery Precautions Any battery may present a risk of fire, explosion, or chemical burn if abused. Do not try to charge a battery that is not intended to be recharged, do not incinerate, and

do not puncture. Non-rechargeable batteries, such as

alkaline batteries, may leak if left in your product for a long period of time. Remove the batteries from the product if you are not going to use it for a month or more.

cause skin burns or other persona

environment by recycling or disposing of batteries according to federal, state, and local regulations

in sunlight or close to fire)

Before you begin

Plugging in for power AC OUTLET POWER SUPPLY: 120V~60Hz

LASH AND

HE TRIANGLE IS A

VARNING SIGN ALERTING YOU OF

"DANGEROUS VOLTAGE" INSIDE THE

The AC power plug is polarized (one blade is wider than the other) and only fits into AC power outlets one way.

If the plug will not go into the outlet completely, turn the plug over and try to insert it the other way. If it still does not fit, contact a qualified electrician to change the outlet, or use a different one. Do not attempt to bypass this

Battery back-up operation

- The power failure protection circuit will not operate unless battery is
- When the battery backup functions, the digital display will not light, however, the wake function still occurs during the power interruption if remaining battery power is adequate.
- Normal operation will resume after AC power is restored so you will not have to reset the time or wake.

Install battery as follow:

- Remove battery compartment door (located at the bottom of the radio) by applying thumb pressure to the tab on battery door and then lift the door out and off the cabinet.
- 2. Connect a 9-volt battery (not supplied) to the connector plug
- 3. Replace the compartment door.

Power failure indicator Vhen AC power is interrupted (disconnected) for a short period of time, both time and alarm settings will change (unless battery is installed). After AC power is restored (reconnected), the Digital Display will blink to indicate that power was interrupted and you should readjust the time and alarm settings.

Power is fed to the unit even when it is not functioning. To cut the power supply off, the power cable must be unpluge

Alkaline (NEDA 1604A/IEC 6LR61) battery is recommended. Carbon-zinc battery may be used but memory holding time will be substantially reduced. Memory holding time for a fresh alkaline battery is approximately 8 hours (if radio or alarm are not operated) which should take care of short, nuisance-type AC power failures. To preserve battery life, the unit should remain plugged into an AC outlet. As the battern gets older, its voltage drops and memory may be lost. Be sure to replace the battery periodically. Battery should be removed if the unit will be stored for more than one month. Leaky battery can badly damage the clock radio.

General controls

When a cart is used, use caution

when moving the cart/apparatus combination to avoid injury from

lightning storms or when unused

required when the apparatus has

been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled

or objects have fallen into the

apparatus, the apparatus has been

exposed to rain or moisture, does

ADDITIONAL SAFETY INFORMATION

device and it should remain readily

operable during intended use. In

order to disconnect the apparatus

mains plug should be disconnected

from the mains completely, the

form the mains socket outlet

Main plug is used as disconnect

not operate normally, or has been

Unplug this apparatus during

for long periods of time. Refer all servicing to qualified

service personnel. Servicing is

tip-over.

Front view

completely.



Right view



SNOOZE (on top of unit) - enter snooze mode where the alarm will quiet but sound again once the snooze period

ON (RADIO) - turn on the radio.

FWD ▶ - set clock or wake time

WAKE MODE - select wake mode

SET ₹ / ⊗ / ○ - slide switch to set

-VOLUME+ - adjust volume.

TUNING - select radio frequencies.

Clock

(

Setting clock time

- 1. Slide the switch **SET** ◀ / ⊗ / to
- 2. Press **≪ REV** or **FWD >>** to set the clock time on the large display. The time decrements or increments
- will follow by a faster rate when you press and hold the buttons. The ":" between hour and minute time flashes when you are setting the time. AM or PM icon will als

show beside the time.

3. Slide the switch **SET ♂** / ♡ / ♡ to on position.

Radio

Selecting radio mode

Switching band Slide the BAND switch on the right of

Tuning the radio

the unit to select FM or AM band

Rotate the TUNING knob on the right of the unit to adjust the radio frequency.

Built-in AFC

The Built In Automatic Frequency Control (AFC) works only on FM. It helps Press ON (RADIO) to switch on radio reducing drift on FM reception and keeping the radio locked in on the FM station to which it is tuned.

> When tuning in FM stations, you may notice that the station you are tuning can be well-tuned on two or three nearby points on the dial. Always tune carefully at the loudest and clearest

AM antenna

A built-in ferrite rod antenna eliminates the need for an outside antenna for AM reception. Rotating the unit slightly may improve reception of distant AM

Wake function

1. Slide the switch **SET** ◀ / ♡ / ~ to

- 2. Press **◄ REV** or **FWD >>** to set the
- The time decrements or increments will follow by a faster rate when
- 3. Slide the switch **SET** \P / Θ / \frown to

Selecting wake source You may be woken up by radio o

- 1. Set a wake time (see above
- select a waking mode. Corresponding indicator lights against the wake icon on the small
- **▼** Wake by alarm
- its maximum in about 30 to 45
- Your last tuned radio station will be the wake source if wake by radio is selected.

responsible to restore any personal

any remotes, memory cards, cables, etc. which were originally provided

with the product. However DO NOT

preference settings.
Properly pack your unit. Include

Setting wake time

- nosition.
- wake time on the small display.

- 2. Press WAKE MODE repeatedly to
- カ Wake by radio
- · The unit equips with GRAD-Uvolume will increase gradually to

- Checking wake time The set wake time always shows on the small display with a wake mode
- If wake function is not activated, **OFF** shows on the small display.

Turning off the wake alarm or radio

To silence the wake function To turn off the wake function, press **SNOOZE** on the top of the unit. The wake alarm or radio will be

switched off temporarily. The alarm or radio will be on again when the

snooze period (default: 9 minutes) is

Press **OFF**. The wake alarm or radio

ss WAKE MODE repeatedly unti

- over. (read "SmartSnooze™") . To turn off the wake alarm of
- will activate again the next day unless you switch off the Wake • To disable the wake function completely:

OFF shows on the small display.

$SmartSnooze^{\text{\tiny TM}}$

This operation allows extra sleep time after the wake function is on. The alarm will be off by pressing **SNOOZE**, **ON**, **⋖ REV**, **FWD >** or **SLEEP** until the snooze period is over. Snooze function can be used repeatedly up to 60 minutes. After this, the wake function will turn off

until the next day. To set the "quiet" period: 1. Press and hold SNOOZE.

- quiet period that shows on the
- large display.
 The time decrements or increments will follow by a faster rate when
- you press and hold the buttons. nooze period can be set from 1 to 30 minutes (default: 9 minutes).
- 3. Release SNOOZE.

SmartSnooze™ is only available when the switch SET ◀ / ⊘ / ○ — is at the ○ —

OFF - turn off the unit.

◄ REV – set clock or wake time

SLEEP - activate sleep function.

wake or clock time.

BAND - select between AM and FM

In sleep mode, you can set the duration (up to 90 minutes) before the radio turn

- To set the sleep mode: Press **SLEEP** repeatedly to cycle among the sleep times available (90min, 60min, 30min, 15min and
- the large display. The radio will be switched on. The indicator lights against the sleep icon Z[™] on the large display

To check the remaining time in

 Press and hold SLEEP to check the remaining sleep time on the large

To cancel the sleep mode: · If you decide to turn off the unit sooner, press **SNOOZE** or **OFF**.

Warranty information

12 Month Limited Warranty Applies to RCA Audio/Video Products

AUDIOVOX ELECTRONICS CORP. (the Company) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be repaired or replaced with reconditioned product (at the Company's option) ithout charge for parts and repai

To obtain repair or replacement within the terms of this Warranty the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the Company at the address shown below

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, loss/interruptions of broadcast or internet service, to costs incurred for installation, removal or reinstallation of product, to corruptions caused by computer viruses, spyware or other malware, to loss of media, files, data or content, or to damage to tapes, discs, removable memory devices or cards, speakers, accessories, computers,

computer peripherals, other media players, home networks or vehicle

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REDI ACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities ANY IMPLIED WARRANTIES, INCLUDING
ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY, ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER
INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF 24 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY. No person or

representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states do not allow limitations on

how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to How to make a warranty claim: If your product is capable of storing

> digital voice recorder, etc), it is recommended to make periodic backup copies of content stored on the product. If applicable before shipping a product, make a back up copy of content or data stored on the device. Also, it is advisable to remove any personal content which you would not want exposed to others. IT IS LIKELY THAT CONTENTS AND DATA ON THE DEVICE WILL BE LOST DURING SERVICE AND REFORMATTING. AUDIOVOX ACCEPTS NO LIABILITY FOR LOST CONTENT OR DATA, OR FOR THE SECURITY OF ANY

PERSONAL CONTENT OR DATA ON

will be returned with factory

default settings, and without any pre-loaded content which may have been installed in the originally purchased products. Consumer will be responsible for reloading data and content. Consumer will be

return any removable batteries, even if batteries were included with the original purchase. We recommend using the original carton and packing materials. Include evidence of purchase date such as the bill of sale. Also print content (such as an mp3 player, your name and address and a description of the defect. Send via standard UPS or its equivalent to:

> Attn: Service Department. 150 Marcus Blvd., Hauppauge N.Y. 11788 1-877-833-3491 Insure your shipment for loss or damage. Audiovox accepts no

Audiovox Electronics Corp

liability in case of damage or loss en route to Audiovox.
Pay any charges billed to you by

the Exchange Center for service not covered by the warranty.

A new or refurbished unit will be shipped to you freight prepaid.

the remainder of the original product's

For Canada Customers, please ship

Provide you with a new or at our option, a refurbished unit. The exchange unit is under warranty for

What we will do:

warranty period

Audiovox Return Centre c/o Genco 6685 Kennedy Road Unit#3, Door 16, Mississuaga, Ontario 15T 3A5

Sleep function

off automatically.

- OFF. 90min is the default setting) on
- when sleep mode is activated.

Audiovox Electronics Corp., 150 Marcus Blvd., Hauppauge, NY 11788 ©2009 Audiovox Electronics Corp. Trademark(s) ® Registered Marca(s) ® Registrada(s) Printed in China

If your product uses more than one battery, do not mix types and make sure they are inserted correctly. Mixing types or inserting incorrectly may cause them to leak.

Discard any leaky or deformed battery immediately. They may injury. Please help to protect the

Do not expose batteries to excessive heat (for example, by leaving them





